

TUFF-TAPE

<p>DESCRIPTION (Speed, Perfection and Longevity)</p>	<p>Patented PVC tight fibered cotton composite corner tape that is 2” wide, .008” thick and comes in 100’ rolls. Tuff-Tape has recess running the length of tape, which makes folding quick and it is adjustable to any angle. It is great for wet areas around tubs, saunas and shower enclosures where moisture lifts or pops paper tape.</p>
<p>ADVANTAGES</p>	<ul style="list-style-type: none"> • Increases productivity by 50% • Four times stronger than paper tape • PVC fiber composite material will not soften or sag when wet and will stretch with truss up-lift or slight lumber movement • Designed to repair areas where paper tape has failed • Material can be second coated immediately • Only requires light skim coat to finish • Resists tears, cracks and blisters • Can be used on flat surface • Water resistant and rustproof • Material will not blister or fuzz up when sanded • Will not blister, tear, crack or fuzz during sanding and holds a straight line • No nail pops or paint chipping • Do not require fasteners, stapling, or any special tools
<p>WARRANTY</p>	<p>Strait-Flex products are backed by a lifetime warranty. When applied to a sound structure, built on a permanent foundation using recommended application techniques, we warrant that these products will not edge-crack for the lifetime of the structure. Contact Strait-Flex International Inc for complete details.</p>
<p>DIRECTIONS</p>	<ul style="list-style-type: none"> • Cut Tuff-Tape to desired length. • Fold in half at center crease, and then adjust to desired angle. • Apply using liberal coat of all-purpose compound to flat surface, corner or angle with joint knife. • Place Tuff-Tape into wet compound, adjust if necessary to create a straight line and remove excess compound. Adequate amount of compound is required behind Tuff Tape to insure bondability. • Apply a second coat of compound immediately. Lightly skim coat the entire surface of Tuff-Tape and let dry. • Apply final coat if required, same as second coat and let dry. Sand lightly to smooth surface. • Painted surface of Tuff-Tape must be thoroughly dry before applying second paint coat. • Do not use lightweight compounds for bed coat.
<p>STORAGE</p>	<p>Store in dry place protected from moisture</p>

Submittal Approvals:

<p>Job Name:</p>	
<p>Contractor:</p>	<p>Date:</p>