

HUGE

DESCRIPTION (Speed, Perfection and Longevity)	<p>Patented PVC tight fibered cotton composite corner tape that is 4 1/8" wide, 020" thick and comes in 100' rolls.</p> <p>HUGE is designed to span gaps resulting from improperly hung drywall, framing irregularities and common occurrences such as lumber shrinkage and truss uplift. Due to its' rigidity, greater bonding surface and slotted edge, HUGE will remain bonded along edges and maintain a finished appearance. Voids that may occur from lumber movement or shrinkage are undetectable. The material is extremely stable and has high impact strength. Composite material will not delaminate.</p>
ADVANTAGES	<ul style="list-style-type: none"> • Will not edge crack or dent like traditional nail on metal corner beads. • Perfect, straight, strong corners fast.. • Will not sag or soften where large voids occur or fills are needed. • Water resistant and rustproof. • Material can be second coated immediately • Requires a very light fill-coat to finish product. • No nail pops or paint chipping. • Saves 25-50% on installation time. • Material will not fuzz up during sanding. • 100 ft. roll ensure no waste or damage in transit or in rough site conditions. • Doe not require fasteners, stapling, or any special tools
WARRANTY	<p>Strait-Flex products are backed by a lifetime warranty. When applied to a sound structure, built on a permanent foundation using recommended application techniques, we warrant that these products will not edge-crack for the lifetime of the structure. Contact Strait-Flex International Inc for complete details.</p>
DIRECTIONS	<ul style="list-style-type: none"> • Cut Strait-Flex to desired length. Fold in half at center crease and adjust to the desired angle. On an inside corner, adjust less than desired angle and press into compound. This will ensure that Strait-Flex will lay flat on wall. • Cut ends of lengths at a 45-degree angle. This will eliminate slight curl at ends of cut lengths. **No need to remove damaged or cracked corners. • Simply hammer back dents, apply drywall compound and then Strait-Flex corner tape. • Apply using liberal coat of all-purpose compound to corner or angle with joint knife. • Press Strait-Flex into wet compound, adjust if necessary to create a straight line and remove excess compound. Adequate amount of compound is required behind Strait-Flex to insure bondability. • Apply a second coat of compound. • Lightly skim coat the entire surface of Strait-Flex. • Apply final coat if required, same as second coat and let dry. Sand lightly to smooth surface. • Painted surface of Strait-Flex must be thoroughly dry before applying second paint coat. • Do not use lightweight compounds for bed coat.
STORAGE	<p>Store in dry place protected from moisture</p>

Submittal Approvals:

Job Name:	
Contractor:	Date: